

Read Before Use

This oiler is supplied with Way Oil 150 (ISO VG 68). We can supply it in quarts, Pt.# 002-0102, or in gallons, Pt.# 002-0126.

To fill, pull off the red cap on the top with your hand, it should come right off. Stick your finger down into reservoir; it is wide and it distributes the load better; hook the plastic seal and pull with a little bit of force. Do not jerk or use wire hook. The seal should tip sideways and you can pull it out. Fill to within ½” of the top, insert the seal and replace the red cap. Refill the reservoir before it gets completely empty.

H&W Machine Repair and Rebuilding – 2119 Meyer Road – Fort Wayne, IN 46803
Phone: (800) 285-5271 – Fax: (260) 423-9476 – E-Mail: hwmachrep@gmail.com
Visit our Website at: www.machinerypartsdepot.com

Read Before Use

This oiler is supplied with Way Oil 150 (ISO VG 68). We can supply it in quarts, Pt.# 002-0102, or in gallons, Pt.# 002-0126.

To fill, pull off the red cap on the top with your hand, it should come right off. Stick your finger down into reservoir; it is wide and it distributes the load better; hook the plastic seal and pull with a little bit of force. Do not jerk or use wire hook. The seal should tip sideways and you can pull it out. Fill to within ½” of the top, insert the seal and replace the red cap. Refill the reservoir before it gets completely empty.

H&W Machine Repair and Rebuilding – 2119 Meyer Road – Fort Wayne, IN 46803
Phone: (800) 285-5271 – Fax: (260) 423-9476 – E-Mail: hwmachrep@gmail.com
Visit our Website at: www.machinerypartsdepot.com